
# CE 3372 WATER SYSTEMS DESIGN PUMPS AND LIFT STATIONS PART 2 (FALL 2020)

## SELECTING PUMPS


- Design conditions are specified
- Pump is selected for the range of applications
- A System Curve (H vs. Q) is prepared
- System Curve is matched to Pump Curve
- Matching point (Operating point) indicates the actual working conditions

### SYSTEM CURVES

- •A system (characteristic) curve is a plot of required head versus flow rate in a hydraulic system (H vs. Q)
  - The curve depicts how much energy is necessary to maintain a steady flow under the supplied conditions
  - Total head, H<sub>p</sub> = elevation head + head losses



### SYSTEM CURVES



$$H_p = (30) + H_{\text{Loss}} = 30 + (f\frac{L}{D} + K_{\text{entrance}} + K_{\text{bend}} + K_{\text{exit}})\frac{Q^2}{A^2 2g} = 127Q^2 + 30$$

### SYSTEM CURVES

This relationship tells us that the added head has to be at least 30 meters just to keep the reservoirs at the two levels shown, if any flow is to occur the pump must supply more than 30 meters of head.

$$H_p = (30) + H_{\text{Loss}} = 30 + (f\frac{L}{D} + K_{\text{entrance}} + K_{\text{bend}} + K_{\text{exit}}) \frac{Q^2}{A^2 2g} = 127Q^2 + 30$$


### **PUMP CURVES**

- Provided information from the manufacturer on the performance of pumps in the form of curves.
- Information may include:
  - discharge on the x-axis
  - head on the left y-axis
  - pump power input on the right y-axis
  - pump efficiency as a percentage
  - speed of the pump (rpm)
  - NPSH of the pump




Sovereign 125 x 80-200


### CENTRIFUGAL PUMP PERFORMANCE DATA



# PUMP CURVES





- Pump A cannot meet the needs of the system at any flow rate
- Pump B supplies enough head over part of the system curve
- The shaded area is the area where the pump supplies excess head



### MULTIPLE PUMPS

Series and parallel combinations can be used to adjust "pump curves" to fit system requirements.





Parallel pumps add flow for given head

Series pumps add head for given flow

