

---

## Section 10 — Regression Equations Method

Regression equations are recommended as the primary hydrologic method for off-system (non-TxDOT) projects; for on-system projects, they are recommended as a check on other methods. Omega EM regression equations are reliable beyond 10 sq. mi. drainage area. A comparison method should be used for drainage areas below 10 sq. mi. and must be used for drainage areas below about 5 sq. mi. This method should not be used for drainage areas less than 1 sq. mi.

Discretion may be used on off-system bridges and culverts. As the design of these crossings is typically "hydraulically same or slightly better," the importance of having an exact flowrate is of lesser importance than on-system crossings. At the engineer's discretion, the use of a comparison method may be disregarded.

If an adequate record of streamflow is not available at or near the project site, an LPIII distribution cannot be developed with Bulletin #17B procedures. An alternative for estimating the needed design flow is to use a regression equation.

Regression equations are used to transfer flood characteristics from gauged to ungauged sites through the use of watershed and climatic characteristics as explanatory or predictor variables. USGS has developed such regression equations for natural basins throughout the State of Texas.

### Procedure for Using Omega EM Regression Equations for Natural Basins

Equations have been developed for natural basins in 1-degree latitude and longitude quadrangles in Texas. Figure 4-5 shows the geographic extents of each quadrangle. The approach used to develop the regional equations is referred to as the "Regression Equations for Estimation of Annual Peak-Streamflow Frequency for Undeveloped Watersheds in Texas Using an L-moment-Based, PRESS-Minimized, Residual-Adjusted Approach." (USGS 2009) For development and use of regression equations a natural basin is defined as having less than 10 percent impervious cover, less than 10 percent of its drainage area controlled by reservoirs, and no other human-related factors affecting streamflow (USGS 2001). The equations are therefore not applicable to urban watersheds.




Figure 4-5. OmegaEM ( $\Omega$ ) quadrangles for Texas regression equations. To view a .pdf of this image, click [here](#).




Figure 4-6. Mean annual precipitation, in inches

Equation 4-12 is the general form of the Omega EM regression equation for Texas:

$$Q_T = P^c S^d \times 10^{[e\Omega + a + bA^l]}$$

Equation 4-12.

**Where:**

$Q_T$  = peak discharge of recurrence interval  $T$  years (cfs)

$P$  = mean annual precipitation in inches from Figure 4-6

$S$  = dimensionless main channel slope

$\Omega$  = OmegaEM from Figure 4-5

$A$  = contributing drainage area ( $\text{mi}^2$ )

$l$  = a power determined by iterative PRESS-minimization for the recurrence interval

$a, b, c, d, e$  = regression coefficients specific for the recurrence interval

Mean annual precipitation is the arithmetic mean of a suitably long period of time of total annual precipitation in inches. The mean annual precipitation was assigned based on the approximate center of the watersheds. Asquith and Roussel (2009 TxDOT 0-5521-1) considers that any general and authoritative source of mean annual precipitation for any suitably long period (perhaps 30 years) is sufficient for substitution into the regression equations.

Main channel length is defined as the length in stream-course miles of the longest defined channel from the approximate watershed headwaters to the outlet. Main channel slope is defined as the change in elevation, in feet, between the two end points of the main channel divided by the main channel length in feet.

OmegaEM ( $\Omega$ ) parameter represents a generalized terrain and climate index that expresses relative differences in peak-streamflow potential not represented in the watershed characteristics of drainage area, slope, and mean annual precipitation.

Since the gauges used to develop the equations are points in space, and that the variables used (contributing area, slope, precipitation) are actually attributes of that specific point, the OmegaEM should also pertain to the point in question. As such, if the contributing drainage area overlaps more than one quadrant on Figure 4-5, the OmegaEM must not be weighted or averaged. The OmegaEM specific for the quadrant of the site must be selected.

The summary of weighted-least-squares, PRESS-minimized, regional regression equations using drainage area, dimensionless main-channel slope, mean annual precipitation, and OmegaEM are provided in Table 4-4.

RSE, residual standard error in  $\log_{10}$  units of cubic feet per second; Adj., adjusted; AIC, Akaike Information Criterion; PRESS, PRediction Error Sum of Squares.

**Table 4-4: Regression Equations**

Regression Equations	RSE	Adj. R-squared	AIC statistic	PRESS statistic
$Q_2 = P^{1.398} S^{0.270} \times 10^{[0.776\Omega + 50.98 - 50.30A^{-0.0058}]}$	0.29	0.84	273	64.6
$Q_5 = P^{1.308} S^{0.372} \times 10^{[0.885\Omega + 16.62 - 15.32A^{-0.0215}]}$	0.26	0.88	122	49.1
$Q_{10} = P^{1.203} S^{0.403} \times 10^{[0.918\Omega + 13.62 - 11.97A^{-0.0289}]}$	0.25	0.89	86.5	46.6
$Q_{25} = P^{1.140} S^{0.446} \times 10^{[0.945\Omega + 11.79 - 9.819A^{-0.0374}]}$	0.26	0.89	140	49.5
$Q_{50} = P^{1.105} S^{0.476} \times 10^{[0.961\Omega + 11.17 - 8.997A^{-0.0424}]}$	0.28	0.87	220	55.6

Table 4-4: Regression Equations

Regression Equations	RSE	Adj. R-squared	AIC statistic	PRESS statistic
$Q_{100} = P^{1.071} S^{0.507} \times 10^{[0.969Q + 10.82 - 8.448A^{-0.0467}]}$	0.30	0.86	320	64.8
$Q_{500} = P^{0.988} S^{0.569} \times 10^{[0.976Q + 10.40 - 7.605A^{-0.0554}]}$	0.37	0.81	591	98.7