

Precipitation


Four variables of interest

- 1) Space : average (equivalent) rainfall over area
- 2) Intensity : how hard it rains
- 3) Duration : how long at a given intensity
- 4) Frequency : how often at a given intensity & duration

Point precipitation analysis

Data from a single gage is often useful for small project design

ACCUMULATED DEPTH



$$\text{Intensity} = \frac{d_2 - d_1}{t_2 - t_1} \quad \left. \vphantom{\frac{d_2 - d_1}{t_2 - t_1}} \right\} \text{Slope of cumulative catch}$$

$$= \frac{\Delta d}{\Delta t}$$

Δt is called the duration

t is a critical design value.

Consider that a 15-minute rainfall event produces:

one 15-minute duration event

six 10-minute duration "events"

11 5-minute duration "events" (3 5-minuteⁱⁿ sequence)


15 1-minute duration "events"

Typically - 15-minute is the smallest time interval usually available; sometimes 5-minute.

Any shorter is by differencing the signal

Acc. DEPTH

*
Rain gauges report "tips" - if data are uniform space in time, they have been "processed" at least once!



if interested in this minute, have to difference 5 & 10



Browser address bar: <http://www1.ncdc.noaa.gov/pub/orders/cdo/390512.csv>

Navigation: Texas Tech U...lty & Staff U.S. Citizens... Case Status The Eco

URL: <http://www1.ncdc.noaa.gov/pub/...>

STATION	STATION_NAME	DATE	QGAG	QPCP	DATE	CATCH, HUNDRETHS-INCH	MISSING DATA CODE
COOP:415410	LUBBOCK	9 N TX US	20130101	00:00	23	-9999	
COOP:415410	LUBBOCK	9 N TX US	20130101	00:15	0,0		
COOP:415410	LUBBOCK	9 N TX US	20130102	16:30	24	-9999	
COOP:415410	LUBBOCK	9 N TX US	20130109	17:15	25,10		January 7th storm.
COOP:415410	LUBBOCK	9 N TX US	20130109	18:30	26,10		
COOP:415410	LUBBOCK	9 N TX US	20130109	19:30	27,10		
COOP:415410	LUBBOCK	9 N TX US	20130109	20:00	28,10		
COOP:415410	LUBBOCK	9 N TX US	20130109	20:30	29,10		
COOP:415410	LUBBOCK	9 N TX US	20130109	20:45	30,10		
COOP:415410	LUBBOCK	9 N TX US	20130109	21:15	31,10		
COOP:415410	LUBBOCK	9 N TX US	20130110	04:45	32,10		
COOP:415410	LUBBOCK	9 N TX US	20130131	23:45	32	-9999	
COOP:415410	LUBBOCK	9 N TX US	20130201	00:00	32	-9999	
COOP:415410	LUBBOCK	9 N TX US	20130201	00:15	0,0		
COOP:415410	LUBBOCK	9 N TX US	20130212	04:00	34	-9999	
COOP:415410	LUBBOCK	9 N TX US	20130212	04:30	35,10		
COOP:415410	LUBBOCK	9 N TX US	20130212	05:00	36,10		

↑ TYPICAL HISTORICAL DATA FROM NWS.
 I CHOOSE LUBBOCK, 15-MINUTE PRECIP.

2-SERIES QGAG & QPCP

QGAG means 1/4 hour Fischer-Porter
 gage values are used

QPCP is 1/4 hour gage values

In above screen capture units are in 1/100th
 inches.

	A	B	C	D
1	TIME-MIN	DEPTH-IN		
2	0	0		
3	15	0		
4	30	0		
5	45	0		
6	60	0		
7	75	0		
8	90	0		
9	105	0		
10	120	0		
11	135	0		
12	150	0		
13	165	0		
14	180	0		
15	195	0		
16	210	0		
17	225	0		
18	240	0		
19	255	0		
<hr/>				
67	975	0		
68	990	0		
69	1005	0		
70	1020	0		
71	1035	0.25		
72	1050	0.25		
73	1065	0.25		
74	1080	0.25		
75	1095	0.25		
76	1110	0.51		
77	1125	0.51		
78	1140	0.51		
79	1155	0.51		
80	1170	0.78		
81	1185	0.78		
82	1200	1.06		
83	1215	1.06		
84	1230	1.35		
85	1245	1.65		
86	1260	1.65		
87	1275	1.96		
88	1290	1.96		
89	1305	1.96		
90	1320	1.96		
91	1335	1.96		
92	1350	1.96		
93	1365	1.96		
94	1380	1.96		
95	1395	1.96		
96	1410	1.96		
97	1425	1.96		
98	1440	1.96		
99				

↑
24 hours
of precipitation

lots of
zeros

Consider the 97 rows of a time-depth series for the

9 JAN 2013 storm.

A tool to "automatically" analyze the data and find the maximum intensity.

The next sheet shows a script that reads the two

columns and then plots the data, then searches and finds the maximum intensity.



Suppose we want to "analyze" the
January 9th storm.

First extract the data -

Put into a time series -

Convert incrementals into cumulative -

Analyze as needed -

Suppose wanted to find the largest intensity
over any 15-minute interval for the January 9th
Storm?

Fairly easy by just looking -

largest increment is 0.31 inches at
hour 21:15

$$\therefore \text{intensity} = \frac{0.31 \text{ inches}}{0.25 \text{ hrs}} = 1.24 \text{ inches/hour.}$$

However, sometimes the time series are too long
to easily read - then we want a
tool to search for the value.

For example, suppose the entire 24 hrs (in 15
minute intervals is supplied)


R Console

```
~/Desktop
> source("/Users/cleveland/Sites/module1/LubbockStorm.R")
```

[1] 0.31

Maximum Intensity for 15-minutes is 1.24 inches per hour

Quartz 2 [*]



```
LubbockStorm
<functions>
# analysis lubbock 9 Jan 2013 rainfall
dummy<-read.csv("LubbockStorm.csv",header=T) #read
the data
# check that read is good
summary(dummy)
# attach column names
attach(dummy)
# plot the time series
plot(TIME.MIN,DEPTH.IN,type="s",lwd=5,col="blue")
# find the largest 15-minute incremental change
biggestchange <-0 # set biggest to zero to start
for (index in 2:length(DEPTH.IN)){
  test <- DEPTH.IN[index]-DEPTH.IN[index-1];
  if(test > biggestchange) biggestchange <- test;
}
print(biggestchange) # print result
# now convert into an intensity
intensity <- biggestchange/0.25
message("Maximum Intensity for 15-minutes is
",intensity," inches per hour")
```

message(... domain = NULL, appendLF = TRUE)


The script above is typical - often software can make the conversions. HEC-HMS has ability to do the conversions.

Cleveland
CE3354
7/7

Here is same data entered into HEC-HMS.

Notice that the cumulative plots look the same (they should)

The incremental plot is shown here



Hms does not directly compute peak intensity (but it can be tricked - using a basin area of $1/640 \text{ mi}^2$, the peak discharge in cfs will be peak intensity in in/hr - in this case 1.25 in/hr which is pretty close to 1.24 in/hr.